

Using the Record Player In Your Rental

Model: AKAI Professional BT500

Quick Start Guide

1. Turn on the record player (switch on the back left).
 2. Turn on the Marshall speaker and set the source to RCA.
 3. Lift the dust cover.
 4. Place your record on the turntable.
 5. Set the speed (33 or 45 RPM).
 6. Unlock and cue the tonearm, then gently lower it onto the record.
 7. Adjust the volume using the Marshall speaker.
-

Full Instructions

1. **Turn On the Record Player:**
Flip the power switch on the back left side to ON.
2. **Turn On the Speaker:**
Ensure the Marshall speaker is powered on and the source is set to RCA.
3. **Remove the Dust Cover:**
Gently lift off the clear dust cover and set it aside.
4. **Choose a Record:**
Carefully remove a vinyl from its sleeve, holding it by the edges to avoid touching the grooves.
5. **Place the Record on the Turntable:**
Center the record over the spindle.
6. **Set the Speed:**
Use the speed selector to choose 33 or 45 RPM. (Most albums play at 33 RPM; singles at 45 RPM.)
7. **Cue the Tonearm:**
 - Unlock the tonearm clip.
 - Gently lift the cue lever.
 - Position the tonearm over the desired starting point.
 - Lower the cue lever to gently place the needle onto the record.
8. **Adjust Volume:**
Control the volume through the Marshall speaker.
9. **When You're Done:**
 - Lift the cue lever to raise the needle.
 - Return the tonearm to its resting cradle and secure the clip.
 - Turn the power switch OFF.
 - Replace the dust cover.

Care Tips for the Player and Records

- Always lift and lower the tonearm using the cue lever.
 - Handle records only by the edges.
 - Never leave a record spinning unattended.
 - Return records to their sleeves immediately after use.
 - If a record looks dusty or needs cleaning, let us know — we're happy to take care of it!
-

Thank you for treating the music (and the equipment) with care.

We hope you enjoy adding a little soundtrack to your stay! 